Configuration LMA-LED



Configuration LMA-LED



Configuration LMA-LED



Configuration LMA-LED



Configuration LMA-LED



Configure the LMA-LED.

Connect configuration cable, install and start LMA-LED.exe.

Press the WRITE or READ button to establish the connection, visible by the large yellow arrow.

The measuring range of 0...100°C is fixed and cannot be changed.

Configuration settings that are made must be transferred to the LMA with the WRITE button.

With the button READ configuration data can be read out from the LMA.

Under File 3, configuration settings can be saved or read.

With the button PRINT the configuration can be printed.